

Installing Static Line on a Para-Cushion Seat (Model 304 or 306)



Strong Enterprises

"The parachute company with imagination"

Division of S.E. Inc.

6448 Pinecastle Blvd Suite 104, Orlando, FL 32809

Tel. (407) 859-9317 Fax: (407) 850-6978

www.strongparachutes.com sales@strongparachutes.com

Install the Static Line

1
Run the ripcord through the small ring on the container.



2
Run the ripcord through the solid ring on the end of the static line.



3
Run the ripcord through the large ring on the container.



4

Attach static line to container by mating Velcro. Stow static line in retainer bands located on container.

NOTE:

In order to avoid excess bulk stow two lengths of static line per retainer band.

**5**

Leave enough static line un-stowed so that the rapide link can be attached to the aircraft anchor point. Strong Enterprises provides a ring tab that can be moved along the velcro riser channel. This tab is for attachment of the rapide link for storage and transportation purposes only.



When in the aircraft the rapide link must be attached to the aircraft anchor point and fully closed for the static line to function properly.