## Para-Cushion Fitment Guide

The chart below, assembled through 4 decades of putting thousands of parachutes in dozens of different aircraft, is intended to provide general guidance.

There are other important factors to consider when making this choice: height, weight, cockpit space restrictions (e.g. headroom), and the field elevations over which you fly.

Strong has a long history of helping Pilot's achieve a solution that works for them and their aircraft. Call us to discuss your specific needs in more detail..

		303	304	305	306	307	311	314	I-39	
MODEL	"ACRO PRO"	"BACK"		"X-COUNTRY"	"SQDN SEAT"				"CHAIR"	
CONFIGURATION	(BACK)	(BACK)	(SEAT)	(BACK/CHAIR)	(SEAT)	(BACK)	(BACK)	(SEAT)	(BACK/CHAIR)	NOTES
										1 - Compatible w/26 FT Mid-Lite
CANOPY COMPATIBILITY	1, 2	1, 2, 3	1, 2, 3	1, 2, 3	1, 2, 3	1, 2	1, 2	1, 2	3	2 - Compatible w/ Lo-Po Lite
										3 - Compatible w/ 30 FT Conical
ACRO SZD59	✓	<b>&gt;</b>								
ACRODUSTER			✓	`						4 - With Travel Cushion
ACROSPORT		<b>√</b>	✓				✓			5 - Modified
APPLE BAY ZUNI		✓					✓			6 - With 2" Travel Cushion
ASW 25 & 27		✓								7 - Purposely built for this aircraft
BD-5 MICROJET				√,8						8 - Requires cockpit measurements
BERKUT				✓						
BOWERS FLYBABY			✓							
BUCKER JUNGMANN			✓							
CAP 10		<b>√</b>		√			✓			
CAP 231 & 232							✓			
CHRISTEN EAGLE		<b>√</b>					✓			
CHRISTEN EAGLE II			<b>√</b>				✓			
CESSNA AEROBAT & 152	✓	<b>√</b>					✓			
CESSNA 172, 182, 205, 206, 207	✓	<b>√</b>					✓			
CITABRIA			<b>√</b>				✓			
CJ-6					✓					
CORSAIR					√					
<b>CURTISS-WRIGHT MODEL 19</b>			✓							
DECATHLON			✓				✓			
DEHAVILLAND DHC-1 CHIPMUNK					✓					
DISCUS		✓								
DR 109			✓							
DUO DISCUS	✓	✓								
EXTRA 200, 230				√						
EXTRA 300, 300L/LX, 300S (REAR)				√						
EXTRA 300, 300L/LX, 300S (FRONT)	✓	<b>✓</b>								
EXTREME AIR XA42	✓			✓						
F1 ROCKET	✓						<b>√</b>			
FIRE BOLT			✓							

## Para-Cushion Fitment Guide

		303	304	305	306	307	311	314	I-39	
MODEL	"ACRO PRO"	"BACK"		"X-COUNTRY"	"SQDN SEAT"			"RV-4 SEAT"	"CHAIR"	
CONFIGURATION	(BACK)			(BACK/CHAIR)	(SEAT)	(BACK)	(BACK)		(BACK/CHAIR)	NOTES
FOCKEWOLFE					<b>√</b>					
FOUGA JET			√, 4							
GILES 200, 202				✓						
GLASAIR					√,5					
GREAT LAKES			<b>√</b>							
GROBE 103				✓						
GRUMMAN WARBIRDS					<b>√</b>					
HARMON ROCKET							<b>√</b>			
L-19 & L-29					<b>√</b>					
L-29 DELFIN									√,7	
L-39 ALBATROS									√,7	
LS8	√	<b>√</b>								
LANCAIR		<b>√</b>								
LIBERTY XL-2	<b>√</b>									
MXS-RH	<b>√</b>									
MX2	<b>√</b>						<b>√</b>			
N3N					<b>√</b>					
ONE DESIGN AKA JAC 1				✓						
P-51 MUSTANG					✓					
P-47				✓						
PI 49D FOCKE-W306					✓					
PILATUS P3					<b>√</b>					
PITTS MODEL 12			<b>√</b>				<b>√</b>			
PITTS S1 & S1 C			<b>√</b>				<b>√</b>			
PITTS S2B (REAR)							<b>√</b>			
PITTS S2B (FRONT)			<b>✓</b>							
PITTS SPECIAL			<b>√</b>				<b>√</b>			
PT-13					<b>√</b>					
PT-19					<b>√</b>					
PW-5		<b>√</b>								
RV-3	√		<b>√</b>							
RV-4 (REAR)	√						<b>√</b>			
RV-4 (FRONT)					_			<b>✓</b>		
RV-6	✓						<b>√</b>			
RV-6A	√	<b>√</b>								

## Para-Cushion Fitment Guide

		303	304	305	306	307	311	314	I-39	
MODEL	"ACRO PRO"	"BACK"				"SUKHOI"		"RV-4 SEAT"	"CHAIR"	
CONFIGURATION	(BACK)	(BACK)		(BACK/CHAIR)	(SEAT)	(BACK)	(BACK)		(BACK/CHAIR)	NOTES
RV-8 (REAR)	<b>√</b>				,		<b>√</b>			
RV-8 (FRONT)								<b>√</b>		
RYAN PT-22			√,6							
SCHLEICHER ASW 24, 27, 28, 29							✓			
SCHLEICHER AGS 29 Es							✓			
SCOUT			✓							
SKYBOLT			✓							
SKYRAIDER			✓							
SNJ					✓					
SOCATA TB 30				✓						
SPITFIRE					<b>√</b>					
STARDUSTER			✓							
STAUDACHER 3 300, 600, 900				✓						
STEARMAN (BUCKET SEAT)					<b>\</b>					
STEARMAN (FLAT SEAT)				<b>✓</b>						
STEMME		<b>\</b>		<b>✓</b>						
STEWART S-51										
SUKHOI SU-26						√,7				
SUKHOI SU-29, SU-31	✓	✓								
SUPER BLANIK	✓	✓								
SWIFT							✓			
T-28					<b>√</b>		✓			
T-33					✓					
Т-6					✓					
T-34 A or B					✓					
TAYLORCRAFT BC-12D	✓									
TBM AVENGER					√					
TS11 ISKRA			✓							
VELOX REVOLUTION		✓					✓			
VENTUS 2CM				✓						
VULTEE BT-13					✓					
WACO			✓							
XAMANGO SUPER										
YAK 11 & 18A			√,4							
YAK 3 & 50			$\checkmark$							

## Para-Cushion Fitment Guide

		303	304	305	306	307	311	314	I-39	
MODEL	"ACRO PRO"	"BACK"	"SEAT"	"X-COUNTRY"	"SQDN SEAT"	"SUKHOI"	"WEDGE"	"RV-4 SEAT"	"CHAIR"	
CONFIGURATION	(BACK)	(BACK)	(SEAT)	(BACK/CHAIR)	(SEAT)	(BACK)	(BACK)	(SEAT)	(BACK/CHAIR)	NOTES
YAK 52, 54, 55			√,4							
ZIVKO EDGE	√	<b>√</b>								
ZLIN 50		<b>√</b>						·		