



Packing Instructions Aerodyne Semi-Stowless Main Deployment Bag

1.



The Aerodyne Semi-Stowless Main Deployment bag will come with 3 grommet locking stows and can be identified by the black webbing tuck tab pocket and a total of four molded tuck tabs.

2.



Insert canopy into the main deployment bag. Starting with the center, route the large packing rubber bands through the corresponding grommet and secure line bite approximately 1.5-2 inches in length using the double stow method.

3.



Center locking stows are to be made before moving along to the outer locking stows. All locking stows are to be free and clear of each other.

4.



Open the line stow flap and route the excess suspension line over the top of the bag down to the bottom of the line stow flap. Begin creating figure 8 line placement starting at the bottom center of the line stow flap.

5.



Continue figure 8 line placement into the line stow flap ensuring the figure 8 remains between the tuck tabs. Ensure excess suspension line exits the center notch of the line stow flap.

6.



Rotate the bag forward on top of the lines and secure the side tuck tabs.

7.



Make sure to stow the top tuck tabs.

****Order of closing tuck tabs is at the discretion of the end user, however it is important to stow all 4 tuck tabs.**

8.



The Aerodyne Semi-Stowless Deployment bag is now closed and ready to be placed carefully into the harness container main tray. Complete the closing sequence as per the manufacturer's recommendations.